



1. FLAG BANNER **CONTENT** AND GRAPHIC **PREPARATION**

TEXTILE BAG NO CUT


 **CONTENT**




Open the bag, check the content of the bag and take out all the pieces carefully.

This flag banner features a light-weight curved aluminium structure that is assembled in a few seconds by joining the ends marked with pairs of numbers and colours. A padded canvas bag is included for transport.


GRAPHIC ATTACHMENT **BY TENSION FABRIC**



To mount the flag banner, you must first slide the printed fabric (supplied separately) through this tube system and then tighten it at the bottom by tying it to the clip.





For those cases in which the graphic is **supplied by the client**, we recommend making use of the materials listed in the following **QR code** (scan for downloading Excel file). Please contact us or visit www.cashdisplay.com for more information.





2. SET UP THE **POLE** AND FIT **THE FLAG**


TEXTILE BAG NO CUT











SCREW THE TUBE TO THE BASE (SUPPLIED SEPARATELY)